

ETP-SMB NEMA 4X Surface Mount Box with Door Installation Instructions

I. Introduction

The **ETP-SMB** is used in conjunction with an ETP-500, VOIP-500, or VOIP-600 Series Call Station.

II. Installation



IMPORTANT NOTE: It is the installer's obligation to ensure compliance with all national, regional, and local regulations and building codes.

1. **For surface mounting**—Mount the ETP-SMB onto a stud wall, cement block, brick, or other wall type with appropriate bolts/washers (not provided) via the four (4) slots on top and bottom flanges.
2. **For wall mounting**—Mount the ETP-SMB onto a pole with two (2) metal straps/hose clamps (not provided) by feeding them through the two (2) vertical slots on the top flange and two (2) vertical slots on bottom flange.
3. Connect 1/2-inch conduit to the 7/8-inch conduit hole in the center of the bottom of the ETP-SMB to connect the communication cabling.
4. All cable pairs/conductors must test free of shorts, opens, and grounds. If auxiliary input and/or auxiliary output leads are to be used, they may be pulled through the same conduit as the communication cable.